



APPLICATION INSTRUCTIONS

CERAMIC **GRAPHENE** Wipe-On Exterior Protectant

STEP 1

Begin with a **clean** surface.

STEP 2

With a **dry, clean** applicator sponge or an orbital polisher, apply a thin layer of NanoCure® Ceramic Graphene Wipe-On Exterior Protectant to the vehicle's painted and chrome surfaces, as well as the headlight lenses and clear-coated factory aluminum wheels.

NOTE: Do not apply NanoCure Ceramic Graphene Wipe-On Exterior Protectant to plastic trim or black trim molding.

STEP 3

Once completely dry, use a clean microfiber towel to remove protectant haze using small, circular movements. If streaking or shadowing occurs, rub areas with a clean, damp microfiber towel, then dry them with a clean microfiber towel.

NOTE: Turn the towel as necessary so that it continues to wipe the surface to a brilliant shine.

Important: Never use a dirty microfiber towel, applicator sponge, polishing pad or trigger sprayer that has been used to apply any other chemical.



Scan this code for additional detail resources



INSTRUCCIONES DE APLICACIÓN

C E R A M I C **GRAPHENE**

Wipe-On Exterior Protectant

(PROTECTOR EXTERIOR DE LIMPIEZA)

PASO 1

Comience con una superficie **limpia**.

PASO 2

Con una esponja **seca** y **limpia** o un pulidor orbital, aplique una capa delgada del NanoCure® Ceramic Graphene Wipe-On Exterior Protectant a las superficies pintadas y de cromo del vehículo, así como a los lentes de las luces frontales y las ruedas de aluminio de fábrica con recubrimiento transparente.

NOTA: No aplique el NanoCure Ceramic Graphene Wipe-On Exterior Protectant a las molduras plásticas o negras.

PASO 3

Una vez se haya secado por completo, use una toalla de microfibra limpia para retirar la bruma de protector con movimientos circulares pequeños. Si se producen rayas o sombras, frote las áreas con una toalla de microfibra limpia y húmeda, y luego séquelas con una toalla de microfibra limpia.

NOTA: No aplique mucha agua en la toalla de microfibra. Solo se requiere un rocío ligero.

Importante: Nunca vuelva a usar una toalla de microfibra, esponja de aplicación, almohadilla de pulido o atomizador de gatillo sucios que se hayan usado para aplicar cualquier otro protector NanoCure.



Escanee este código para obtener recursos adicionales detallados