NanoCure®

APPLICATION INSTRUCTIONS

SOUND BARRIER (SOLVENT BASED)

STEP 1
Application should be performed in a well ventilated area. Ensure the surface to be sprayed is **dry** and **clean** of debris or buildup.

STEP 2
Before opening NanoCure® Sound Barrier, shake it well. Attach a bottle of Sound Barrier to the spray gun and adjust regulator pressure to 60 p.s.i.

STEP 3
Raise the vehicle on a lift to waist high, or approximately 3 feet. Spray each wheel well first, keeping the tip of the nozzle inside the exterior line of the fender well.

STEP 4
Raise the vehicle to allow standing room underneath. Spray the under body panels starting from one side and spray towards the center of the vehicle. Repeat that process from the other side of the vehicle to minimize overspray and clean up.

NOTE: Avoid spraying the exhaust, plastic components and any parts that may heat up as well as mechanical parts, including brake components, emergency brake cables and drive train. Also, do not spray any wires, harnesses or connectors that may need to be accessed by Service personnel.

STEP 5
Remove Sound Barrier overspray with solvent based tar, wax and grease remover.

GUN CLEANING: Immediately after job is complete and before Sound Barrier has begun to dry inside the gun, spray a canister of solvent-based tar, wax and grease remover into a trashcan with a plastic can liner.

Refer to the Safety Data Sheet for recommended protective gear.

© 2022 NanoCure Protective Coatings, Inc.

MODO DE EMPLEO

SOUND BARRIER (BASE DE SOLVENTE)

(AISLANTE ACÚSTICO)

PASO 1

La aplicación debe realizarse en un área bien ventilada. Cerciórese de que la superficie que va a rociar esté **seca** y **libre** de residuos o acumulación de mugre.

PASO 2

Antes de abrir el NanoCure® Sound Barrier, agítelo bien. Fije una botella del Sound Barrier al atomizador y ajuste la presión del regulador a 60 p.s.i.

PASO 3

Eleve el vehículo a la altura de la cintura, o aproximadamente 90 centímetros (3 pies). Primero rocíe bien el interior de cada compartimiento de las llantas, manteniendo la punta de la boquilla adentro de la línea exterior del guardabarros.

NOTA: No rocíe los componentes del compartimiento de la llanta que no sean de metal.

PASO 4

Eleve el vehículo para permitir que haya espacio para estar de pie debajo de él. Al rociar los paneles de la carrocería inferior, comience en un lado y rocíe hacia el centro del vehículo. Repita este proceso desde el otro lado del vehículo para minimizar el exceso de rociado y limpieza.

NOTA: Evite rociar el tubo de escape, los componentes de plástico y cualquier parte que pueda calentarse así como las partes mecánicas, incluyendo los componentes de los frenos, los cables del freno de mano y la transmisión. Tampoco rocíe los cables, arneses o conectores a los que se deba acceder para el mantenimiento del vehículo

PASO 5

Limpie cualquier exceso de rociado con agua si el Sound Barrier **no está seco**. Si ya se secó el Sound Barrier, retírelo con NanoCure Spray-On Exterior Protectant.

LIMPIEZA DEL ATOMIZADOR: Inmediatamente después de terminar el trabajo y antes de que se haya comenzado a secar el Sound Barrier al interior del atomizador, rocíe un recipiente lleno con agua en un basurero con el interior forrado con una bolsa de plástico. Si el Sound Barrier se ha secado adentro del atomizador, se debe usar un removedor base solvente de alquitrán, cera y grasa en lugar de agua.

© 2022 NanoCure Protective Coatings, Inc.